

WARNING!

HOT WORK IN PROGRESS Watch for Fire!

		Construction Factors					
		Non Combustible construction		Combustible construction without concealed cavities		Combustible construction with unprotected concealed cavities	
		Watch	Monitor	Watch	Monitor	Watch	Monitor
Occupancy Factors	Noncombustible with any combustibles contained within closed equipment (e.g. ignitable liquid within piping.)	30 mins	0 hours	1 hour	3 hours	1 hour	5 hours
	Office, engineering, retail or manufacturing with limited combustible loading	1 hour	1 hour	1 hour	3 hours	1 hour	5 hours
	Manufacturing/Engineering with significant combustible loading	1 hour	2 hours	1 hour	3 hours	1 hour	5 hours
	Warehousing	1 hour	2 hours	1 hour	3 hours	1 hour	5 hours
	Bulk storage of combustible materials capable of supporting slow growing fires (e.g. paper, pulp, textile fibres, wood, bark, grain, coal, or charcoal.)	1 hour	3 hours	1 hour	3 hours	1 hour	5 hours

Notes: Fire Watch means continuous watch over the entire hot work area.

Fire monitoring can include one of the following methods:

- A.** Automatic smoke detection system with remote alarm that sounds in a constantly-attended location.
- B.** Security video cameras with clear coverage of the hot work area. Locate camera displays in a constantly-attended location. Cameras with infrared capability are preferred.
- C.** Operators routinely present in the hot work area. Train operators to monitor for fire-safe conditions, maintain required precautions in place, and notify emergency contacts before making any attempt to extinguish the fire.
- D.** Personnel to intermittently patrol the hot work area for fire-safe conditions. At a minimum, patrol the hot work area at least every 15 minutes. Train personnel to monitor for fire-safe conditions, maintain required precautions in place, and notify emergency contacts prior to attempting to extinguish a fire, regardless of size.

**For more information, please consult FM Global Data Sheet 10-3 by visiting:
www.fmglobalsdatasheets.com.**

IN CASE OF EMERGENCY CALL:

Emergency Services	--	(1) 111
POAL Emergency Number	--	09 348 5777
Multi-Cargo Duty Supervisor	--	09 348 5346 (Mon to Fri 07:00 - 23:00, Sat 07:00-15:00)
Outside Operating Hours	--	09 348 5000 ext. 5702 (please note a call out charge may apply)
Engineering Duty Supervisor	--	09 348 5261
Container Terminal Duty Manager	--	09 348 5322
Radio Channel	--	1A, 4A
	--	VHF ch12 (or RT ch5A)
For emergency on board ship, inform Harbour Control	--	VHF ch12

Other:.....
.....
.....